

Spectrum Pro Dispenser

Instructions for use



Maintenance

Front panel access

Open front panel to install refill cartridge, change batteries, or adjust the amount dispensed during each use.

1. Press maintenance mode button located on the front left underside of the dispenser (**Figure 1**). This pauses the motion sensor for 30 seconds. This button can also be used to prevent waste when cleaning the area below the dispenser.
2. Insert key in slot at rear left or right under dispenser, seen in **Figure 2** (either side will work).
3. Push key up until it clicks and the front cover releases to swing open.
4. Removable key may be used to limit access, or thumb tab key may be left in place for convenience.



Figure 1



Figure 2

Installing and replacing refill cartridges

Refill cartridges slide in and out of place requiring no other release mechanism (**Figure 3**).

1. Remove empty dispenser cartridge by sliding it straight out from dispenser.
2. Install new cartridge by lining up refill bottle with slots in dispenser and you should feel it click gently into place.



Figure 3

Adjusting amount dispensed

This adjustment feature lets you select 3 different amounts of product dispensed.

1. With cartridge bottle removed, access the orange bar on the dispenser (**Figure 4**).
2. Adjust usage amount from 0.5, 1.0, and 1.5 mL by moving the orange bar from left to right (**Figure 5**), respectively. It is easily adjusted using a pen or other pointed object.



Figure 4



Figure 5

0.5,
1.0,
and 1.5 mL

Replacing batteries (4 Type D required)

1. To replace batteries, open front panel as discussed above. Slide out cartridge bottle if there is one in place (**Figure 3**).
2. Press in gray lever at the back of the bottle neck insertion area and swing down the battery access panel (**Figure 6**).
3. Check batteries for proper installation using the image to the right (**Figure 7**), or the + and - signs on the access panel door. Replace as needed with fresh D batteries.
4. Close the battery panel, slide cartridge back in place and close the front panel. Pass hand under sensor a few times to prime the unit until it begins dispensing.



Figure 6



Figure 7

NOTE: Make sure the battery indicator flashes green and that product dispenses properly. If not, check batteries for proper installation and power.



Battery indicator light

When dispenser is used, the light on the lower right side of the dispenser flashes green when batteries are in good condition; or red when batteries need to be replaced or are loaded improperly.



Installation

Scan the code to view the installation video.



Enjoy simplified hand hygiene compliance with Spectrum.